



WARNINGS:

AFTER USE, RELEASE ANY REMAINING PRESSURE BY LIFTING THE QUICK RELEASE PRESSURE RELIEF VALVE (7) UPWARD. **DO NOT** STORE SPRAYER PRESSURISED, ENSURE TRIGGER LOCK IS RELEASED.

ADJUST SPRAY PATTERN BY ROTATING NOZZLE (6)

FIRMLY CLOSE THE SCREW CAP (2)

PUMP HANDLE (3) UNTIL RESISTANCE IS FELT (APPROXIMATELY 30 STROKES).

SPRAY BY PRESSING DOWN BUTTON (4)

FOR CONTINUOUS SPRAYING PRESS BUTTON (4) DOWN AND SLIDE THE TRIGGER LOCK (5) FORWARD

FILL THE SPRAYER AS FAR AS THE 1.5 LITRE FILL LINE (1). **DO NOT** OVERFILL OTHERWISE THE SPRAYER MAY NOT PROVIDE FULL PRESSURE.

