

**TELESCOPIC POLE
FOR ELECTRIC SECATEURS BCL25IB
BCL25TP**

BAHCO®

Quick Guide

EN	2
CZ	4
DE	6
EL	8
ES	10
FR	12
IT	14
NL	16
PL	18
PT	20
SK	22
TR	24
BS	26
DA	28
FI	30
HU	32
NO	34
RU	36
RO	38
SL	40
SV	42



List of icons with explanation



Special safety precautions when working with electric secateurs



Risk of injury – keep hands away from cutting head



Never use this pole within 50 feet (15 m) of power lines or electrical wires. Failure to heed this warning may result serious injury or death by electrocution



Do not expose to rain, water or wet conditions



Keep away from heat sources



Do not use damaged or broken batteries



Wear safety glasses



Wear safety gloves



Read the user guide




Do not put to general waste




Recycle in accordance with local waste regulation


1. Getting started




Unscrew the cover securing screw



Open the cover-head of the telescopic pole




Insert connector into the secateurs



Insert secateurs into the head of the telescopic pole



Close the cover-head of the telescopic pole




Screw the cover securing screw




Insert battery into the telescopic pole

After installation, press on/off button and double-click trigger to open the blade and start working. When installing or dismantling the secateurs, be sure to switch off the tool.

2. Telescopic pole length adjustment




Press the handle to the end to fix the telescopic pole to the selected length



The length of the telescopic tube can be adjusted by loosening the handle

3. Telescopic pole head special treatment



Do not rotate the telescopic pole head, the service life of the tool will be shortened